



PIR

The passive infrared (PIR) sensor is installed in the home and programmed to detect activity or inactivity depending on the needs or condition of the user. When the programmed activity is not carried out it activates an alarm call so that the user can be attended to.

All the assurance you need

Tunstall