

product data



pillow alert solution

What is the Pillow Alert Solution?

The Pillow Alert Solution provides an alert to a sleeping user by the use of a smoke detector linked to a vibrating pad, which is positioned underneath the users pillow. The solution also features a strobe light to provide an additional level of warning when the user is out of bed.

How does it work?

On detection of smoke, the dedicated smoke detector will automatically activate the vibrating Pillow Alert pad and the Strobe Unit will flash alerting the user to the potential problem. The solution can be linked to Lifeline home units or to other Tunstall telecare enabled systems. By linking the solution to home units it ensures that a 24 hour response centre is alerted automatically in addition to the user.

Why is it needed?

Fire poses one of the most serious threats to people at home and its effects are devastating. Every year fires in the home cause hundreds of deaths and damage many thousands of homes.

Who is it for?

Installing a Pillow Alert solution helps alert users with hearing impairments to the activation of a smoke detector. By means of a visual indication or a physical vibration of the pillow pad. Because the process is automatic and immediate the risk to life and property is reduced.



All the reassurance you need

Tunstall

Features and benefits

- BS standard compliant - the linked smoke detector is compliant with the required standards
- Visual indication - strobe unit provides visual alert for added protection
- Vibrating pillow pad - positioned under the pillow to waken sleeping users
- Compatible with telecare

Technical details

Main Control Unit

Weight:	600g
Dimensions:	100 x 160 x 50mm (WxHxD)
Power supply:	12v AC

Pillow Alert

Dimensions:	90 x 35mm (WxH)
Power supply:	Optical

Smoke Detector

Weight:	150g
Dimensions:	140 x 120 x 50mm (WxHxD)

Standards:

CE:	Compliant
Design, Manufacture, Installation and Service:	ISO9001: 2000

Part Number: *i9000/72*

Please Note: Requires installation

Tunstall

www.tunstallgroup.com

Tunstall is a founder member of the Continua Health Alliance

Our policy of continual development means that product specification and appearance may change without notice. Tunstall does not accept responsibility for any errors and omissions contained within this document.

© 2007 Tunstall Group Ltd. ® TUNSTALL, AMIE and LIFELINE are registered trademarks.

Tunstall Group Limited, Whitley Lodge, Whitley Bridge, Yorkshire DN14 0HR
Tel: 01977 661234 Fax: 01977 662450 Email: enquiries@tunstall.co.uk

